
TUBULAR HEATER INSTRUCTION MANUAL



Tubular Heater :TH01A,TH02A,TH03A,TH04A

YOU SHOULD READ THE MANUAL CAREFULLY BEFORE USING, AND KKEP THE MANUAL WELL.



DISPOSAL

This symbol indicates that this product must not be placed in general household waste. It should be sent to a separate recycling facility for recovery, check Local Authorities for details.

By responsible recycling and separating this product from other household waste it will help protect the environment and human health, as the volume of waste sent to incinerators or land-fills will be reduced and natural resources conserved.



Read all the instructions prior to use.



This item gets very hot: do not touch the tubular heater when it is switched on.

Do not cover the tubular heater as this will cause overheating.

Never place the tubular heater directly on the floor without using the feet.

WARNING: Check product before use: if cord is damaged, it must be replaced by the manufacturer if still under warranty, or a similar qualified person to avoid any hazards

1. Safety Regulations

- During the first use the heater may emit a small amount of vapour which is perfectly normal. The reason for this is the heating wire element is coated with some lubricant oil during the production process. This will stop after approx 5 minutes after the first use and is not a safety concern.
- · It is important all electrical devices are plugged into power that is protected by a safety switch.
- The tubular heater is not suitable for use outdoors in damp weather.
- Do not submerge into water.
- · Place in a safe place away from flammable objects.
- Do not place flammable liquids or gasses near the heater.
- Do not place the heater directly below the socket outlet.
- Do not let the power cord over hang or touch the tube.
- Keep out of reach of children and animals product gets hot to touch.
- · This is not a toy.
- · Switch off appliance when not in use.
- Do not hold the tubular heater by the cord.
- · If using an extension cord it must be as short as possible and fully extended.
- Check heater regularly if using with a timer or any other device that switches the tubular heater on or off automatically.
- This leaflet should be retained for instructions on use.

2.Cleaning

Ensure product is unplugged from the mains. Ensure product is completely cold.


Wipe with a damp cloth, then finish by drying with a soft cloth. DO NOT use abrasive cleaning powders, clothes or metal polishes on any part of the tubular heater as this will cause damage.

3.Thermal Cut-out


The appliance is fitted with a thermal cut-out. Once the tubular heater has cooled down it will re-set itself automatically. It will then switch on and off until the reason for overheating has been removed.

5. Operation for tubular heater TH01A, TH02A, TH03A, TH04A, TH05A, TH06A

Notice: DO NOT SWITCH POWER ON TO THE HEATER UNTIL IT IS SECURELY MOUNTED.



Step 1. Install the bracket as the picture showed .



Step 2. Fix the tubular heater on the wall or on the floor like the following picture showed .



6. Tubular heater features

• Tubular Heater TH01A,TH02A,TH03A,TH04A: basic model, with thermostat.

7. Tubular Heater Notice:

- The temperature will then be regulated and kept at a constant level by the thermostat.
- The heater is fitted with a safety device which will switch off the heater in case of accidental overheating .
- Make sure that any causes of overheating, such as obstructions, are removed and plug the appliance in again.
- •When it is summer or nobody at home or no need to keep heating , please pull out the plug.

8. Tubular heater Specifications

Model No.	Power	Electrical Supply	IP Rating	Product Length (mm)	Product pack size (mm)
TH01A	60W	220-240V ,50 Hz	IP55	300mm	385*95*90
TH02A	120W	220-240V ,50 Hz	IP55	600mm	685*95*90
TH03A	180W	220-240V ,50 Hz	IP55	900mm	995*95*90
TH04A	240W	220-240V ,50 Hz	IP55	1200mm	1295*95*90
TH03A	300W	220-240V ,50 Hz	IP55	1500mm	1595*95*90
TH04A	360W	220-240V ,50 Hz	IP55	1800mm	1895*95*90

This product is guaranteed under warranty and covers defects in material or workmanship from 1 year of date of purchase. The original bill of purchase (with purchase date) must be submitted.

The warranty will not apply in cases of: Misuse: by non-compliance of the instructions, normal wear and tear, incorrect use, e.g. overloading, non-approved accessories, force or damaged caused by external forces, if the plug has been tampered with or removed, partially or completely dismantled product, or interference by non-qualified persons.